

TracPhone® Satcom Application Note



AppNote0805

June 26, 2008

Configuring Outlook®, or Other POP/SMTP Mail Client, to Send Ship-to-Shore E-mails via mini-VSAT BroadbandSM

To send outgoing e-mails via the TracPhone® V7 and mini-VSAT Broadband service, configure your Windows e-mail client as described below (*Windows Vista screens shown*).

Note: The mini-VSAT Broadband SMTP server is only available while your TracPhone V7 is logged into the mini-VSAT Broadband service. Sending e-mail from other networks, such as home or enterprise networks, will not work properly.

1. Open Outlook (or other POP/SMTP mail client).
2. From the **Tools** menu, select **Accounts** to bring up the Internet Accounts window.
3. At the Internet Accounts window, select **Properties** for your Mail account.
4. Select the **Servers** tab.
5. Write down the current setting for “Outgoing mail (SMTP)” for future reference.
6. In the “Outgoing mail (SMTP)” text box, enter **tnsmtp.kvh.com**. *Do not change your incoming mail (POP) setting.*
7. Select **Apply** then **OK**.

Your outgoing e-mail will now be relayed by the tnsntp.kvh.com SMTP server on the mini-VSAT Broadband network.

