

IsatPhone^{PRO}

quick start guide




The mobile satellite company™


inmarsat


insert the SIM card

- Remove the battery cover by using a coin to turn the screw slot until it is vertical.
- If the battery is in place, lift it out.
- Slide the catch down on the SIM holder and flip it outwards.
- Make sure the angled corner of your SIM card is on your left and slide it into the holder.
- Flip the holder back into place and slide the catch back up.
- Insert the battery, replace the cover and turn the screw slot until it is horizontal.



charge the battery

Connect the charger to a power source and the micro USB connector to the port at the base of the phone.





switch on

Hold down the red key  until the screen lights up. The first time you use your phone, use the navigation keys to select your language and set the time zone. To switch off, hold down the red key  until the screen shuts down.

connect to the satellite

Stand outside with a clear view of the sky and the phone antenna pointing upwards. The top left of the screen will display 'Inmarsat' once you are connected to the satellite. At least 2 signal bars are required to make and receive calls.



Note: Before you make a call, your phone needs a GPS fix so it can be located by the satellite. This happens automatically, but if a new GPS fix is needed, the  icon will be displayed. Place the phone in the open with a clear view of the sky until the  icon disappears.

make a call

Enter the full international number by dialling +, country code, area code (without the leading 0), telephone number and press the green key  eg. +44 1621 123456 . To end a call, press the red key .


answer a call

When your phone rings, press the green key . Remember, to receive a call, you must be connected to the satellite with the phone antenna pointing upwards.

listen to voicemail

Hold down the  key and you will automatically be connected to your voicemail. Alternatively, call +870 772 001 899 and press the green key .

your IsatPhone^{PRO}



	Signal strength
	Product name
	Network
	Local time
	Battery
	Alarm active
	New voicemail
	Unread message
	Active profile
	Status bar
	Information shortcut
	Left selection label
	Right selection label

further information

Please refer to the CD, which contains a full user guide and applications for contact synchronisation, firmware upgrades and USB drivers. Also available at inmarsat.com/isatphone



Remote Satellite Systems
INTERNATIONAL

TOLL FREE 1-888-989-8199

1455 N. Dutton Suite A, Santa Rosa, CA 95401
FAX 707-546-8198 • info@remotesatellite.com
www.remotesatellite.com

While the information in this Quick Start Guide has been prepared in good faith, no representation or warranty, express or implied, is made or given as to the adequacy, accuracy, reliability or completeness of such information. Inmarsat Global Limited nor any group company or their respective officers, employees or agents shall have any responsibility or liability to any person resulting from the use of the information in this Quick Start Guide. Copyright © Inmarsat Global Limited 2010. All rights reserved. INMARSAT is a registered trademark of the International Mobile Satellite Organisation; the Inmarsat LOGO is a registered trademark of Inmarsat (IP) Company Limited. Both trademarks are licensed to Inmarsat Global Limited. IsatPhone Pro QSG June 2010.